

GAME INSTRUCTIONS MG - 311

BREAK AWAY

CONTENTS					P	age
INTRODUCTION						1
1. GAME OBJECTIVE						1
 2. GETTING STARTED		I A SUCCESSION IN			•	1
 3. START TO PLAY a) ONE PLAYER b) TWO PLAYERS c) PLAYER VS COMPUTER 		· ·				6
 4. END OF GAME			•	•		6
5. START NEW GAME			•	•		7
6. SCORING						7
7. OPERATION FLOW DIAGRAM						8

BREAK AWAY

BREAK AWAY the bricks in the wall and escape!

You are trying to escape from custody by smashing a hole in a thick brick wall. This is not as easy as it sounds – your only tools are balls and a paddle, and in some versions the wall is defended.



Once you have mastered the first game, attempt the more difficult versions – try knocking down an invisible wall with a smaller paddle that gets even smaller as the game progresses!

1. GAME OBJECTIVE

The object of the game is to score points by knocking down the brick wall. Points are given for each brick knocked away, and additional bonus points are awarded if the entire wall is demolished.

There are 16 different versions of the game and three special options for each version, to provide games with varying levels of difficulty. For games involving only one player, the aim is to score as many points as possible. For those involving two players, or one player versus the computer, the one with the highest score wins.


2. GETTING STARTED

Plug in the antenna cable and AC adaptor plug of the Master Console in accordance with the instructions given

in the Master Console Installation Manual (MPT-03).

a) INSERT CARTRIDGE

Slide the power switch of the Master Console to the OFF position. Hold the cartridge with the slots facing the player and insert into the cartridge opening.



Note: The Console should be switched OFF when inserting/removing the cartridge to avoid damage to the Master Console and the cartridge

b) HAND CONTROLLERS

The paddles are controlled by horizontal movements of the joysticks. Use only the left hand controller when there is only one player or when playing against the computer.

c) VERSION AND OPTION SELECTION Switch ON Master Console

Game 1 of Break Away (the basic version) automatically appears on the TV screen.

Press button A -

until the desired version of Break Away is displayed on the TV screen.

Game Selection Table

Game	No. of Players	Game Limit	Features*
1	ONE	6 balls	Basic
2	ONE	6 balls	GUIDED BALLS
3	ONE	6 balls	CATCH BALL
4	ONE	6 balls	PENETRATING BALL
5-8	TWO	5 minutes	Same as Versions 1-4 respectively
9-12	PLAYER VS COMPUTER	5 minutes	Same as Versions 1-4 respectively
13-16		5 minutes	Same as Versions 1-4 respectively, but with 'shrinking' paddle.

Press button B -

to choose one of the three special options.

Press button B	Option*
once twice three times	invisible wall option paddle size option invisible wall and paddle size options combined

d) GUIDE TO GAMES

(i) Basic

This is the basic Break Away game without any special features.

* For details see 2(d)

(ii) GUIDED BALLS

The return path of the ball after each strike can be guided by moving the joystick to the left or the right.

(iii) CATCH BALL

The ball can be caught with the paddle by pressing the HOLD button on the keypad of the hand controller. The ball and paddle can then be moved to the desired position with the joystick and releasing the HOLD button.

(iv) PENETRATING BALL

The ball passes through the bricks and only rebounds when it hits the back wall and the rear side of the bricks. Therefore an entire section of wall can be broken away with just one strike.



(v) "SHRINKING" PADDLE

A piece of the paddle is knocked away when it hits the ball (or when it is hit by a rebounding ball). A maximum of 5 pieces can be chipped away. For the double-layer paddle, pieces from both layers are knocked away with each strike. "If the paddle has been chipped in the middle, a ball may pass through it instead of rebounding back."



e) SPECIAL OPTIONS

(i) Invisible wall option

The bricks become invisible and only reappear when hit by the ball.

(ii) Paddle size option

For games 1-4, this option provides a narrower paddle. For games 5-16, it provides a double-layer paddle.

3. START TO PLAY

a) ONE PLAYER

Place Break Away inlay plate onto the left hand controller.

Press GAME START button

A ball is served from the centre court.


Move the paddle – to return the ball.



b) TWO PLAYERS

Place both Break Away inlay plates onto the left and right hand controllers.

Press GAME START button – A balk is served from the centre of the screen to the left hand player. By moving their paddles, both players then attempt to demolish the opposite walls, whilst at the same time defending their own walls.



c) PLAYER VS COMPUTER

Place the Break Away inlay plate onto the left hand controller and use only this controller for all player vs computer version.

Follow the instructions as in 3b). The computer replaces the second player.

a) GAMES 1-4

The game is over when all six balls have been served.



b) GAMES 5-16

The game is over when 5 minutes playing time has elapsed.

5. START NEW GAME

a) GAMES 1-4

- Press GAME START button to restart new game immediately while retaining previous highest score.
- (ii) Press CLEAR button to erase all previous information Press button A – to select desired game version Press button B – to select required option Press GAME START button

b) GAMES 5-16

See 5 a) (ii) above

6. SCORING

		ROWS	COLOUR OF BRICKS	POINTS
		6th	BLACK	6
4		5th	RED	
s	-16	4th	BLACK	4
GAMES	5 5	3rd	RED	3
64	GAMES	2rd	GREEN	2
	GA	1st	YELLOW	1


BONUS

If you knock down the entire wall, an additional 100 points are awarded. If this occurs within the time limit, or there are some balls remaining, a new wall will be set up and more points can be scored.

Note: For Games 5-16, only 4 rows of bricks are displayed

Total score = points scored by knocking down + Bonus points the bricks.

7. OPERATION FLOW DIAGRAM



PRINTED IN HONG KONG

88-05201-11